## **BEKA BLOCKS**



Beka blocks are bolted together. Each block can deliver different amounts of grease to each point.

The delivery quantity of each block is stamped into the side of each block



When connecting poly tube to the block use brass fittings.



When connecting steel fittings to the block use steel fittings.



Check valves are fitted to the block outlet when grease needs to be prevented from flowing back to the pump.



Cross bridges are available so two blocks can be joined to increase the output to a grease point.



A manual grease point can be added to allow manual greasing of the system.